

Perform the following operations to restore a black screen TV without backlight :

1. Press the button and hold it, then plug in the power cord.



2. Keep holding the button until TV enter recovery mode then you can release it.



3. By connecting to internet (WiFi or Ethernet). TV will download software to fix the issue.

(1) WIFI :



(2) Ethernet :



4. After upgrade, TV will reset and start normally.

