

QUICK START GUIDE



Element, the Element Logo, and Bring it home are trademarks of
Element Brand Holding, LLC. ©2021, Element Brand Holding, LLC, All Rights Reserved.




WHAT'S INCLUDED





Your new TV!

Remote



TV Stand

4 Stand Screws



**2 AAA
Remote
Batteries**

WE'RE HERE TO HELP

Find resources and get help with product setup,
connecting devices, technical issues,
downloading manuals and more!

We're available 24 hours a day, 7 days a week



elementelectronics.com



1.888.842.3577



customerservice@elementelectronics.com

CONNECT DEVICES TO YOUR TV

Check to ensure that you have selected the right cables for the ports and that they are connected securely (*cables and external devices not included*). Loose connections can affect your picture and audio quality. Actual connections may vary by model. Please refer to the actual product.

ANT/CABLE



Connect an outdoor or indoor antenna.

HDMI




Connect a Blu-ray or DVD player, gaming console, streaming device or other external devices to your TV. Highest quality audio/visual connection.

OPTICAL



Connect an optical cable from an external digital audio system.

HEADPHONE



Connect headphones or external speakers.

USB




Connect a USB device for browsing photos, music, movies, or pausing live TV.

CONNECT DEVICES TO YOUR TV

(continued)

composite (good quality)



component (better quality)

Connect a composite video (yellow) or component video (green/blue/red) and left-right audio cables from an external AV device.

SETTING UP YOUR TV

1

Place Batteries in Remote


Power your TV remote by inserting the included batteries carefully matching (+) and (-) indicated inside the battery compartment.

TIP: Always replace dead batteries with two brand-new batteries from the same manufacturer. Never use damaged batteries.

If your remote gets warm/hot during use, discontinue use and contact customer support immediately.



2



Plug in and turn on TV


Plug your TV into the wall outlet and press the power button on your remote control.

Power button



SETTING UP YOUR TV

(continued)



Press the ▼▲◀▶ buttons on your remote to select or change a setting. When you're finished, press MENU to exit the Setup Wizard.

Menu Language: Select the language you want to be displayed in the menu. The default language is English.

Time: Select the time zone and daylight saving time.

Air/Cable: Select whether you want to watch TV with an antenna (Air) or through a cable/satellite box (Cable).

Auto Scan: Search and store available channels automatically.

LET'S REGISTER YOUR PRODUCT



*It's super easy, just head on over to
elementelectronics.com/register*

BENEFITS OF REGISTERING YOUR PRODUCT:



Support

Get assistance quickly by pre-registering your product.



News & Offers

Take advantage of the latest news and special offers from Element.



Updates

Stay current with important product updates and notifications.



Warranty

Receive a 2 year warranty with product registration.*

*1 year manufacturer warranty with purchase or 2 year warranty with product registration within 90 days of purchase.